



7200SB

INDUSTRIAL BLINDSTITCH MACHINE

INSTRUCTION MANUAL

< INSTRUCTION MANUAL >

INDEX

| | |
|---|----|
| 1. Unpacking Machine | 1 |
| 2. Setting-up Machine..... | 1 |
| 3. Handwheel Rotation and Speed..... | 1 |
| 4. Oiling and Maintenance..... | 1 |
| 5. Replacing Needle..... | 2 |
| 6. Threading Machine..... | 3 |
| 7. Inserting the Work and Starting to sew..... | 4 |
| 8. Adjustment of Needle Penetration..... | 4 |
| 9. Stitch Length Regulation..... | 5 |
| 10. Needle Recommendation..... | 5 |
| 11. Skip Stitch Device | 6 |
| 12. Removal of the Work from the Machine | 6 |
| 13. Cloth Retainer Spring Adjustment (for H-101-H)..... | 7 |
| 14. Stitch Stabilizing Guide (for H-1012)..... | 7 |
| 15. Safety Instructions..... | 8 |
| 16. Technician Model Parameter Diagram | 9 |
| 17. Fault Solution Guide | 10 |

1. Unpacking Machine

Open packing box by carefully removing its cover so as not to damage the machine or those of its parts which project from the top, such as the tension parts.

Small accessory parts are packed separately in individual packages. Do not discard any packing materials without prior scrutiny as to contents.

Clean from machine all greases, dirt or dust. Pay particular attention to area around the looper mechanism and looper.

2. Setting-up Machine

Assemble knee lifter lever to machine and place on sewing table so that lever is 13m/m distant from front edge of the table. Line up belt groove in belt pulley of handwheel with belt groove of drive mechanism (motor or clutch).

Mark three screw holes for fastening machine to sewing table and place felt pad under machine bed before machine is tightened down.

3. Handwheel Rotation and Speed

Turn handwheel only in direction away from operator for clockwise rotation. Be sure motor drive is wired up to obtain the same clockwise rotation. The recommended operating speed of a brand new machine is 1,800 to 2,000 stitches per minute. After a breaking-in period of several weeks and after the operator has become skilled in the operation of the machine, the speed can be increased up to 2,500 stitches per minute.

4. Oiling and Maintenance

It is important not to operate the machine before oil of good quality has been filled in each and every oil hole along the top of the machine. When breaking-in a new machine oiling should be done sparingly several times a day. Thereafter, one oiling daily will be sufficient. After oiling, wipe machine carefully to avoid soiling of the material.

Do not operate without material under the presser foot unless the knee lever is depressed. This will prevent damage to the needle and the feed dog as well as the feed plattens.

5. Replacing Needle

Turn handwheel away from operator (clockwise) until needle reaches the end of its return stroke (extreme left hand position). Adjust penetration dial to least amount of penetration (turn clockwise towards 1).

Remove old or defective needle by loosening needle clamp screw. Insert new needle into seat in needle clamp as far as it will go. Tighten needle clamp screw.

Turn handwheel slowly away from operator and observe movement of needle. The curved portion of the needle should bear slightly on the needle guide groove in the left hand part of the presser foot.




Fig. 1

Always replace bent or blunt needles. They affect the satisfactory operation of the machine. (see Fig. 1)

See par. 10 concerning needle sysetm to be used in Blindstitch Machines.

6. Threading Machine


Turn handwheel of machine in clockwise direction away from operator until needle carrier reaches its furthest lefthand position.

And proceed as follows :

Draw thread from spool on thread stand and pass it through thread guide (A) which is located on rear side of thread nipper.

Place thread between tension discs of thread nipper and thread tension and lead it forward through thread guide (B) and pass it through thread guide (C) at the top of the arm near its front.

From there pass thread through hole in needle clamp and then through the eye of needle from below upward. Pull about 5 cm of thread through the eye of needle. (see Fig 2)



7. Inserting the Work and Starting to Sew

Depress knee lifter. This causes the feed plate to swing downward and creates a gap between the presser foot and the feed plate.


Insert the work in the gap just opened in such a manner that the folded or sewn edge of the material is alongside the edge guide of the presser foot. (see Fig. 1)

When the material is in proper position, completely release the knee lifter. Get the machine started slowly and watch the material pass edge guide rather than to observe the action of the needle.

8. Adjustment of Needle Penetration

The type of material to be blindstitched governs the degree of needle penetration which is required. It is, therefore, recommended to stitch a few centimeters as a test and make adjustments for penetration depending on the appearance of the trial stitching.

Turn regulator clockwise for less penetration and counter-clockwise for more penetration. (Fig. 3)




9. Stitch Length Regulation

Stitch length adjustment can be easily effected by adjusting needle driving eccentric in arm.

Go about it as follows:

Turn handwheel by hand pushing plunger until same is felt to drop into a recess within the mechanism inside the arm of the machine.

With the plunger remaining depressed into this recess continue turning the handwheel either forward or in reverse until the desired number of stitches per inch is visible on indicator. (see Fig. 4)



10. Needle Recommendation

The recommended needle is system LW x 6T.


| Size | Material |
|---------------|---|
| 3 (11) | Cottons. Silks. Acetates, Orlon, Dacron and similar type of light weight fabrics. |
| 3 1/2 (14) | Medium weight materials. Woolens and Others. |
| 4 (16) | Thick materials for coats, house furnishings. |

11. Skip Stitch Device

The position of grip at the right side of the machine controls the skip stitch device. (see Fig. 5)

When this grip points towards NO SKIP, the needle catches the material at each stitch. Pointing towards SKIP, the needle penetrates the material at every other stitch.

Be sure that grip is pushed completely in either direction and needle penetration readjusted every time operation is changed from skip to nonskip.



12. Removal of the Work from the Machine


Stop machine and turn handwheel away from operator until needle is completely out of the material. Press the knee lifter to the right and pull the work-piece rearward out of the machine with a quick stroke. This will lock the last stitch and break the thread.

13. Cloth Retainer Spring Adjustment (for H-101-H)

The tension of cloth retainer spring can be adjusted by turning the cloth retainer spring adjusting screw (see Fig. 6)

To increase the tension of cloth retainer spring, turn this screw to the right (clockwise). It is suitable for thicker material.

To decrease the tension, turn this screw to the left (counter-clockwise). It is suitable for thinner material.




14. Stitch Stabilizing Guide (for H-1012)

Stitch Stabilizing Guide is effective for soft and uniform stitch on extremely thin material.

If required tight stitch on thin and medium materials, loosen Stitch Stabilizing Guide Set Screw to take off Stitch Stabilizing Guide.

Be sure to tighten Stitch Stabilizing Guide Set Screw firmly on presser foot of same position after took off the Stitch Stabilizing Guide. (Ref. Fig. 7)



CAUTION:Please take good care not to lose Stitch Stabilizing Guide after took off.

1. SAFETY INSTRUCTIONS:

- 1.1. Instruction and trial-run must be done by professional technician;
- 1.2. Please ensure the grounded wire is working well;
- 1.3. Do not step on the foot pedal when motor turns on;
- 1.4. Control box and motor cover are forbidden to be opened when power turn-on;
- 1.5. Please ensure power is off during below operations:
 - a) When threading, changing needle and inner stitching thread;
 - b) When installing machine and maintaining;
 - c) When turning over the machine.

2. OPERATION PANEL INSTRUCTIONS:

2.1. Each Key purpose:

| KEY | SEWING MODEL | FUNCTION MODEL |
|-----|------------------------|--|
| P | Needle position choice | Confirm the operation, it will enter into setting model with other keys; |
| S | LED light on-off | Confirm the parameter setting. |
| + | Sewing speed-up | Key to add parameter and index. |
| - | Sewing slow-down | Key to reduce parameter and index. |

2.2. ADJUSTING TECHNICIAN MODEL PARAMETER:

- a) Press key "P", meanwhile press key "+" once, the screen will show P-OO;
- b) Press key "+" or "-" till the parameter model number required;
- c) Press key "P" into parameter, the screen will show the parameter;
- d) Press key "+" or "-" till the required parameter;
- e) Press key "S" to save parameter and quit.

2.3. RESTORE FACTORY SETTING:

Press key "P", meanwhile press key "+", the screen will show P-00;
Then press key "S" 3 seconds, it will resource factory settings.

3. TECHNICIAN MODEL PARAMETER DIAGRAM:

| Parameter Code | Description | Adjusting Scope | Factory Setting | Remark |
|----------------|-------------------------------|--|-----------------|------------------------------|
| P-02 | Direction of rotation | 0: Reverse turn 1: Clockwise turn | 1 | |
| P-03 | The needle Angle | 6-18 | 12 | |
| P-04 | Sewing-begin speed | 200-800rpm | 250 | |
| P-05 | Speed-up and slow-down | 300-1200 | 850 | |
| P-06 | Setting the seam | 0-999needle | 0 | |
| P-07 | Reserve | | | |
| P-10 | Automatic clearance run | 0: normal sewing 1: automatic clearance run | 0 | Turn off power, running stop |
| P-14 | Maximum current limit | 50-500 | 300 | |
| P-15 | The location of topper needle | 0: No detecting 1: Detecting needle | 1 | |


4. FAULT SOLUTION

| Error Code | Content | Reason |
|------------|--|---|
| Er01 | No found needle position | The gap between handle wheel and motor cover is too big; Nine plug does not connect well; Motor hall broken, it should change new motor; The magnet in handle wheel is lost. |
| Er02 | The speed regulator is not found when power-on | Speed regulator plug not plug-in or badly connected; The speed regulator wire is broken. |
| Er03 | Motor hall or phase error | Nine plug not connected wall; Motor not installed well; Hall broken. |
| Er04 | Lock-rotor protection | Motor overloaded; Motor is not well connected. |
| Er05 | Hardware over-current protection | Motor overloaded; Signal wire badly connected or broken. |
| Er07 | Serial port communication timeout error | The wire between display and main board is not good or main board broken. |

< PARTS LIST >

CONTENTS


| | Page |
|---|------|
| Machine Frame & Covers Components | 1 |
| Main Shaft Mechanism Components | 3 |
| Needle Carrier & Feed Dog Mechanism Components | 5 |
| Looper Drive Mechanism & Presser Foot Parts Components | 7 |
| Ridge Forming Disc & Feed Plate Mechanism Components | 9 |
| Disc Oscillating Mechanism & Knee Press Shaft Parts Components | 11 |
| Thread Tension & Nipper Parts Components | 13 |
| Work Plate, Knee Press & Belt Cover Parts Components | 15 |
| Standard Accessories | 17 |
| Additional Parts for Model H-100 (Non-Skip Stitch) | 19 |
| Additional Parts for Model H-101-H | 21 |




Machine Frame & Covers Components

| Ref. No. | Parts No. | Description |
|----------|-----------|----------------------------|
| 1 | 4139 | Arm Side Cover |
| 2 | 4144 | Arm Side Cover Set Screw |
| 3 | 4137 | Arm Side Cover Plate |
| 4 | 5227 | Arm Side Cover Plate Screw |
| 5 | 4138-B | Arm Top Cover Plate |
| 6 | 4141 | Arm Top Cover Plate Screw |
| 7 | 4140-A | Arm Top Cover Plate Washer |
| 10 | AM100-B | Machine Frame |
| 11 | 11091 | End Cover |
| 12 | 11153 | End Cover Set Screw |
| 13 | 4214 | Machine Base Felt Pad |
| 14 | AC-15 | Machine Base Clamp Screw |
| 15 | AC-17 | Machine Base Washer |
| 16 | AC-16 | Machine Base Nut |

Direct Drive Motor & Components




- | | |
|---|---------|
| 1 | M14-24 |
| 2 | 101SD-1 |
| 3 | LD00271 |
| 4 | LD00003 |
| 5 | LD00237 |
| 6 | LD00003 |




Main Shaft Mechanism Components

| Ref. No. | Parts No. | Description |
|----------|-----------|--|
| 1 | 11005 | Main Shaft Bushing (Front) |
| 2 | 131 | Main Shaft Bushing Set Screw |
| 3 | 4217 | Oiling Felt |
| 4 | 4128-A | Oil Cap |
| 5 | 4133 | Counterweight (w/Stitch Length Numbers) |
| 6 | 132 | Counterweight Set Screw (Short) |
| 7 | 98 | Counterweight Set Screw (Long) |
| 8 | 4134 | Stitch Length Indicator |
| 9 | 124 | Stitch Length Indicator Set Screw |
| 10 | 11006 | Main Shaft Bushing (Rear) |
| 11 | 4003-A | Main Shaft |
| 12 | 6048 | Thread Tension Releasing Eccentric |
| 13 | 96 | Thread Tension Releasing Eccentric Set Screw |
| 14 | 4162 | Skip Stitch Gear (Small) |
| 15 | 96 | Skip Stitch Gear Set Screw |
| 16 | 525-A | Eccentric Rod Assembly (w/Ref. Nos. 17, 18) |
| 17 | 98 | Eccentric Bushing Screw |
| 18 | 105 | Eccentric Rod Set Screw |
| 19 | 4065 | Eccentric Rod Stud |
| 20 | 114-B | Eccentric Rod Stud Set Screw |
| 21 | 4077-A | Skip Stitch Gear Shaft Collar (Small) |
| 22 | 132 | Skip Stitch Gear Shaft Collar Set Screw |
| 23 | 4163 | Skip Stitch Gear (Large) Assembly |
| 24 | 4164 | Eccentric Rod Connection |
| 25 | 4166-A | Skip Stitch Gear Shaft |
| 26 | 131 | Skip Stitch Gear Shaft Set Screw |
| 27 | 4168 | Skip Stitch Gear Shaft Collar (Large) |
| 28 | 132 | Skip Stitch Gear Shaft Collar Set Screw |




Needle Carrier & Feed Dog Mechanism Components

| Ref. No. | Parts No. | Description |
|----------|-----------|--|
| 1 | 4128-A | Oil Cap |
| 2 | 4217 | Oiling Felt |
| 3 | 4023-A | Needle Carrier |
| 4 | 4024 | Needle Carrier Set Screw |
| 5 | 4019 | Needle Carrier Shaft |
| 6 | 4022 | Needle Carrier Shaft Collar |
| 7 | 129-B | Needle Carrier Shaft Collar Set Screw |
| 8 | 4020-A | Needle Carrier Shaft Bushing (Front) |
| 9 | 129-A | Needle Carrier Shaft Bushing Set Screw |
| 10 | 4021-A | Needle Carrier Shaft Bushing (Rear) |
| 11 | 129-A | Needle Carrier Shaft Bushing Set Screw |
| 12 | 4017-A | Needle Carrier Shaft Crank |
| 13 | 4018-A | Needle Carrier Shaft Crank Set Screw |
| 14 | 114-A | Needle Carrier Shaft Crank Clamp Screw |
| 15 | 11139 | Needle Clamp |
| 16 | 121 | Needle Clamp Set Screw |
| 17 | 4181 | Needle (System LW x 6T) |
| 18 | 1151 | Needle Driving Eccentric Assembly w/Rod, Regulator & Screws (Ref. Nos. 19-22) |
| 19 | 4211-C | Ball Connecting Rod Set Screw (Short) |
| 20 | 4173 | Ball Connecting Rod Set Screw (Long) |
| 21 | 4009-B | Needle Driving Eccentric Set Screw |
| 22 | 4012-A | Stitch Regulator Screw |
| 23 | 4010 | Stitch Regulator Ball |
| 24 | 4011-A | Stitch Regulator Spring |
| 25 | 4014 | Ball Connecting Rod Cap |
| 26 | 4015 | Ball Connecting Rod Cap Set Screw |
| 27 | 11902 | Feed Lever |
| 28 | 11124-J | Oiling Felt |
| 29 | 11121 | Oil Cap |
| 30 | 10129 | Feed Dog |
| 31 | 2528 | Feed Dog Washer |
| 32 | 4048-A | Feed Dog Set Screw |
| 33 | 1152-A | Feed Link & Stud |
| 34 | 4173 | Feed Link Clamp Screw |
| 35 | 4042-A | Feed Link Stud Set Screw |
| 36 | 4044 | Feed Link Eccentric Stud |
| 37 | 4043 | Feed Link Eccentric Stud Bushing |
| 38 | 129-A | Feed Link Eccentric Stud Bushing Set Screw |
| 39 | 520-A | Stitch Length Regulating Plunger Assembly |
| 40 | 129-A | Stitch Length Regulating Plunger Set Screw |




Looper Drive Mechanism & Presser Foot Parts Components

| Ref. No. | Parts No. | Description |
|----------|-----------|--|
| 1 | 538-A | Looper Drive Crank Assembly w/Looper Yoke & Screws (Ref. Nos. 2-8) |
| 2 | 4191 | Looper Drive Crank Set Screw |
| 3 | 5039-A | Looper Drive Crank Stud Nut |
| 4 | 129-B | Looper Drive Crank Stud Collar Set Screw |
| 5 | 4030-A | Looper Yoke |
| 6 | 4031 | Looper Yoke Set Screw |
| 7 | 4032-A | Looper Yoke Pin |
| 8 | 8142 | Looper Yoke Pin Set Screw |
| 9 | 539-A | Looper Carrier Assembly w/Ball Joint & Screws (Ref. Nos. 10-15) |
| 10 | 4035-A | Looper Carrier |
| 11 | 4176 | Looper Carrier Nut |
| 12 | 4216 | Looper Carrier Ball Joint Set Screw |
| 13 | 4213 | Looper Carrier Ball Joint Clamp Screw |
| 14 | 4179-D | Looper Carrier Ball Spot Screw |
| 15 | 4040 | Looper Clamp Screw |
| 16 | 4039 | Looper |
| 17 | 505 | Eccentric Sleeve & Pin |
| 18 | 4038 | Eccentric Sleeve Clamp Screw |
| 19 | 4050 | Presser Foot Set Screw |
| 20 | 4061-A | Presser Foot Bracket |
| 21 | 4062 | Presser Foot Bracket Adjusting Screw |
| 22 | 121-B | Presser Foot Bracket Holding Screw |
| 23 | 11158 | Presser Foot Bracket Washer |
| 24 | 4186-A | Presser Foot Holding Screw |
| 25 | PF100 | Presser Foot Assembly (Ref. Nos. 26-40) |
| 26 | 4049-B | Plain Presser Foot |
| 27 | 11563 | Needle Guide |
| 27-1 | 11563-A | Stitch Stabilizing Guide |
| 28 | 4052-B | Needle Guide Set Screw |
| 29 | 4058-A | Chaining Finger |
| 30 | 4185 | Chaining Finger Set Screw |
| 31 | 4055CAS | Cloth Retainer |
| 32 | 4185 | Cloth Retainer Screw |
| 33 | 4056 | Cloth Retainer Spring |
| 34 | 4054 | Cloth Retainer Eccentric Stud |
| 35 | 4183 | Cloth Retainer Eccentric Stud Set Screw |
| 36 | 4053 | Cloth Retainer Eccentric Stud Bushing |
| 37 | 130-B | Cloth Retainer Eccentric Stud Bushing Set Screw |
| 38 | 4057-C | Cloth Retainer Stopper |
| 39 | 4182 | Cloth Retainer Stopper Set Screw |
| 40 | 4059 | Edge Guide |
| 41 | 4185 | Edge Guide Set Screw |




Ridge Forming Disc & Feed Plate Mechanism Components

| Ref. No. | Parts No. | Description |
|----------|-----------|--|
| 1 | 11220-T | Ridge Forming Disc |
| 2 | 4208 | Ridge Forming Disc Nut |
| 3 | 5222-B | Ridge Forming Disc Washer |
| 4 | 8150 | Ridge Forming Disc Positioning Pin |
| 5 | 4109-A | Ridge Forming Disc Shaft |
| 6 | 4111 | Ridge Forming Disc Shaft Collar |
| 7 | 129-B | Ridge Forming Disc Shaft Collar Set Screw |
| 8 | 4112 | Ridge Forming Disc Shaft Crank |
| 9 | 113-B | Ridge Forming Disc Shaft Crank Set Screw |
| 10 | 515-A | Ball Joint & Stud Assembly with Screws (w/Ref. No. 11) |
| 11 | 108 | Ball Joint Set Screw |
| 12 | 4176 | Ball Stud Nut |
| 13 | 4102 | Disc Adjusting Holder |
| 14 | 4108 | Disc Adjusting Holder Pivot Bearing Screw |
| 15 | 98 | Disc Adjusting Holder Pivot Bearing Screw Set Screw |
| 16 | 4107 | Disc Adjusting Holder Pivot Bearing Pin |
| 17 | 98-A | Disc Adjusting Holder Pivot Bearing Pin Set Screw |
| 18 | 4104 | Disc Adjusting Holder Spring |
| 19 | 4105 | Disc Adjusting Holder Spring Screw |
| 20 | 4106 | Disc Adjusting Holder Spring Nut |
| 21 | 4103-A | Disc Adjusting Holder Spring Stud |
| 22 | 5208 | Disc Adjusting Holder Spring Stud Nut |
| 23 | 11075-A | Feed Plate Shaft |
| 24 | 4043 | Feed Plate Shaft Bushing |
| 25 | 98 | Feed Plate Shaft Bushing Set Screw |
| 26 | 4090 | Feed Plate Shaft Collar |
| 27 | 129-B | Feed Plate Shaft Collar Set Screw |
| 28 | 516-B | Feed Plate Assembly w/Screws & Nuts (Ref. Nos. 29, 30) |
| 29 | 4101 | Feed Plate Taper Bearing Screw |
| 30 | 4070 | Feed Plate Nut |
| 31 | 4096 | Feed Plate Shoulder Bearing Screw |
| 32 | 4093-BA | Feed Plate Spring |
| 33 | 4094 | Feed Plate Spring Screw |
| 34 | 4095 | Feed Plate Spring Adjusting Nut |
| 35 | 4097-A | Feed Plate Bracket |
| 36 | 113-B | Feed Plate Bracket Set Screw |
| 37 | 4122 | Disc Adjusting Dial |
| 38 | 4129 | Disc Adjusting Dial Set Screw |
| 39 | 519-AA | Disc Adjusting Regulator Assembly |
| 40 | 4010 | Disc Adjusting Regulator Ball |
| 41 | 4011 | Disc Adjusting Regulator Spring |
| 42 | 115 | Disc Adjusting Regulator Base Set Screw |




Disc Oscillating Mechanism & Knee Press Shaft Parts Components

| Ref. No. | Parts No. | Description |
|----------|-----------|---|
| 1 | 4073-A | Disc Oscillating Rod Bracket Spring |
| 2 | 4074 | Disc Oscillating Rod Bracket Spring Screw |
| 3 | 4075 | Disc Oscillating Rod Bracket Spring Nut |
| 4 | 4169 | Connecting Rod |
| 5 | 4065 | Connecting Rod Stud |
| 6 | 114-B | Connecting Rod Stud Set Screw |
| 7 | S-4066BB | Disc Oscillating Rod Assembly (w/Ref. No. 8) |
| 8 | 129-B | Disc Oscillating Rod Shaft Set Screw |
| 9 | 4115 | Disc Oscillating Rod Pin |
| 10 | 129-A | Disc Oscillating Rod Pin Set Screw |
| 11 | 4065 | Disc Oscillating Rod Stud |
| 12 | 4031-A | Disc Oscillating Rod Stud Set Screw |
| 13 | 4069-A | Disc Oscillating Rod Bracket Spring Stud |
| 14 | 4070 | Disc Oscillating Rod Bracket Spring Stud Nut |
| 15 | 4076 | Disc Oscillating Rod Bracket Shaft |
| 16 | 4077-A | Disc Oscillating Rod Bracket Shaft Collar |
| 17 | 132 | Disc Oscillating Rod Bracket Shaft Collar Set Screw |
| 18 | 131 | Disc Oscillating Rod Bracket Shaft Set Screw |
| 19 | 4098-A | Feed Plate Depressing Crank |
| 20 | 105 | Feed Plate Depressing Crank Set Screw |
| 21 | 4178-A | Crank & Link Shoulder Screw |
| 22 | 5207 | Crank & Link Shoulder Screw Nut |
| 23 | 4086 | Connecting Link (Large) |
| 24 | 4067-A | Connecting Link Guide Screw |
| 25 | 4068-A | Connecting Link Guide Screw Nut |
| 26 | 4083 | Knee Press Shaft Crank |
| 27 | 4084 | Knee Press Shaft Crank Set Screw |
| 28 | 4087 | Connecting Link (Small) |
| 29 | 4088-A | Connecting Link Set Screw |
| 30 | 5207 | Connecting Link Set Screw Nut |
| 31 | 4085 | Crank & Link Shoulder Screw |
| 32 | 4081-A | Knee Press Shaft Bushing |
| 33 | 4206 | Knee Press Shaft Bushing Washer |
| 34 | 4205 | Knee Press Shaft Bushing Nut |
| 35 | 4177 | Knee Press Shaft Sleeve |
| 36 | 11063-A | Knee Press Shaft |
| 37 | 11539 | Knee Press Shaft Washer |
| 38 | 4221 | Knee Press Stop Lever |
| 39 | 4084 | Knee Press Stop Lever Clamp Screw |
| 40 | 4222-A | Knee Press Stop Lever Spring |
| 41 | 4116 | Knee Press Stop Lever Spring Pin |
| 42 | 11050 | Knee Press Stop Lever Limit Screw |
| 43 | 4068-A | Knee Press Stop Lever Limit Screw Nut |
| 44 | 4171 | Skip-Stitch Selecting Grip |
| 45 | 4010 | Skip-Stitch Selecting Ball |
| 46 | 4011 | Skip-Stitch Selecting Spring |
| 47 | 4174 | Skip-Stitch Selecting Spring Holder |
| 48 | 4170 | Skip-Stitch Selecting Grip Bushing |
| 49 | 4172 | Skip-Stitch Selecting Cam |
| 50 | 4173 | Skip-Stitch Selecting Cam Set Screw |
| 51 | 4175-A | Skip-Stitch Selecting Cam Stud |
| 52 | 4070-A | Skip-Stitch Selecting Cam Stud Nut |




Thread Tension & Nipper Parts Components

| Ref. No. | Parts No. | Description |
|----------|-----------|---|
| 1 | 11136 | Thread Guide with Ceramic |
| 2 | 113-A | Thread Guide Set Screw |
| 3 | 81 | Thread Tension Nut |
| 4 | 79-B | Thread Tension Spring |
| 5 | 77 | Thread Tension Washer |
| 6 | 5190-A | Thread Tension Disc |
| 7 | 4204 | Thread Tension Disc Pin |
| 8 | 4209 | Thread Tension Staff |
| 9 | 4068-A | Thread Tension Staff Nut |
| 10 | 4201 | Thread Tension Staff Bracket |
| 11 | 4202 | Thread Tension Releasing Pin |
| 12 | 4203-A | Thread Guide |
| 13 | 4193 | Thread Guide Set Screw |
| 14 | 4199 | Thread Nipper Nut |
| 15 | 4198 | Thread Nipper Spring |
| 16 | 77 | Thread Nipper Washer |
| 17 | 5190-A | Thread Nipper Disc |
| 18 | 5067 | Thread Nipper Staff |
| 19 | 4197 | Thread Nipper Disc Prop |
| 20 | 11162 | Thread Nipper Releasing Pin |
| 21 | 6053 | Thread Nipper Releasing Pin Collar |
| 22 | 130-B | Thread Nipper Releasing Pin Collar Set Screw |
| 23 | 4195-C | Thread Nipper Releasing Pin Support |
| 24 | 8158 | Thread Nipper Releasing Pin Support Set Screw |
| 25 | 4194-A | Thread Nipper Releasing Pin Lever |
| 26 | 8158 | Thread Nipper Releasing Pin Lever Set Screw |




Work Plate, Knee Press & Belt Cover Parts Components

| Ref. No. | Parts No. | Description |
|----------|-----------|--|
| 1 | 4153 | Work Plate |
| 2 | 4156 | Work Plate Latch |
| 3 | 5230 | Work Plate Latch Set Screw |
| 4 | 4157-A | Work Plate Bracket |
| 5 | 4159 | Work Plate Bracket Spring Pin |
| 6 | 4160 | Work Plate Bracket Leaf Spring (Long) |
| 7 | 4161 | Work Plate Bracket Leaf Spring (Short) |
| 8 | 4048-A | Work Plate Bracket Leaf Spring Set Screw |
| 9 | 4158 | Work Plate Bracket Set Screw |
| 10 | 4154-A | Work Plate Shaft |
| 11 | 99-A | Work Plate Shaft Screwed Cap |
| 12 | 4155 | Work Plate Shaft Collar |
| 13 | 132 | Work Plate Shaft Collar Set Screw |
| 14 | 4180 | Work Plate Shaft Set Screw |
| 15 | 4146-A | Knee Press Rod Sleeve |
| 16 | 4147-B | Knee Press Rod Sleeve Set Screw |
| 17 | 4148-A | Knee Press Rod |
| 18 | 4212 | Knee Press Pad |
| 19 | 4149 | Knee Press Plate |
| 20 | 4147-B | Knee Press Plate Set Screw |



Standard Accessories


| Ref. No. | Parts No. | Description |
|----------|-----------|------------------------------|
| 1 | 4152 | Thread Guide |
| 2 | 129-A | Thread Guide Set Screw |
| 3 | 4151 | Spool Pin |
| 4 | 4150 | Cotton Stand Base |
| 5 | AC-10 | Cotton Stand Base Wood Screw |
| 6 | AC-03 | Screw Driver (Small) |
| 7 | AC-02 | Screw Driver (Medium) |
| 8 | AC-01 | Screw Driver (Large) |
| 9 | AC-04A | Oiler |
| 10 | AC-05 | Oil |
| 11 | AC-08 | Accessory Box |
| 12 | 4181 | Needle (System LWx6T) |



Additional Parts for Model H- 100 (Non-Skip Stitch)

| Ref. No. | Parts No. | Description |
|----------|-----------|--|
| 1 | 4145 | Screwed Cap (for hole of Grip 4171) |
| 2 | 4110-AA | Ridge Forming Disc |
| 3 | 507-A | Eccentric Rod Assembly (w/Ref. Nos. 4-6) |
| 4 | 105 | Eccentric Rod Set Screw |
| 5 | 98 | Eccentric Bushing Screw |
| 6 | 4218 | Oiling Felt |
| 7 | 4065 | Disc Oscillating Rod Stud |
| 8 | S-4066AB | Disc Oscillating Rod Assembly (w/Ref. No. 9) |
| 9 | 129-B | Disc Oscillating Rod Shaft Set Screw |
| 10 | 4031-A | Disc Oscillating Rod Stud Set Screw |
| 11 | 4115 | Disc Oscillating Rod Pin |
| 12 | 129-A | Disc Oscillating Rod Pin Set Screw |
| 13 | 4069-A | Disc Oscillating Rod Bracket Spring Stud |
| 14 | 4070 | Disc Oscillating Rod Bracket Spring Stud Nut |
| 15 | 4078 | Disc Oscillating Rod Bracket Adjusting Screw |
| 16 | 4070 | Disc Oscillating Rod Bracket Adjusting Screw Nut |
| 17 | 4067-A | Connecting Link Guide Screw |
| 18 | 4068-B | Connecting Link Guide Screw Nut |

[Parts not listed are common to Model H-101 (See Pages 3 & 11).]



Additional Parts for Models H-101-H

| Ref. No. | Parts No. | Description |
|----------|-----------|--|
| 1 | PF100H | Universal Presser Foot Assembly (Ref. Nos. 2–19) |
| 2 | 4301–C | Plain Universal Presser Foot |
| 3 | 11563 | Needle Guide |
| 4 | 4052–B | Needle Guide Set Screw |
| 5 | 4304 | Edge Guide |
| 6 | 4182–A | Edge Guide Set Screw |
| 7 | 4302–S | Cloth Retainer |
| 8 | 4308 | Cloth Retainer Set Screw |
| 9 | 10037 | Cloth Retainer Holder |
| 10 | 10038 | Cloth Retainer Bracket |
| 11 | 121 | Cloth Retainer Bracket Set Screw |
| 12 | 4312–A | Cloth Retainer Spring |
| 13 | 10040 | Cloth Retainer Spring Adjusting Screw |
| 14 | 10039 | Cloth Retainer Spring Adjusting Screw Prop |
| 15 | 5233–A | Cloth Retainer Spring Adjusting Screw Prop Set Screw |
| 16 | 4311–A | Cloth Retainer Spring Bushing |
| 17 | 15128 | Cloth Retainer Spring Pin |
| 18 | 4058–A | Chaining Finger |
| 19 | 4185 | Chaining Finger Set Screw |



FREQUENTLY ASKED QUESTIONS BLINDSTITCH SEWING MACHINES

Sewing machine operators can often help themselves when their machine does not operate properly. Here are some simple instructions, which if properly used, can save you time and mechanic's service call.

What do I check when the thread breaks?

Poor thread quality (too old, or not strong enough) can cause the machine to skip stitches or break the thread. Make sure you are using the correct needle system, See owner's manual.
Check for defective needle (burr or blunt).
Check for incorrect passing of the thread.
Check thread tension, could be tight.

What do I check when the needles are breaking?

Select the correct needle size for the type of work being done.
Make sure the needle is inserted correctly.
Make sure you are using the correct needle system, See owner's manual.
The ridge-forming disc may be set too high. Gradually turn the dial regulator in the "less" direction.
Check to see if the looper is deflecting off the needle as it travels pass the needle.

What do I check when the thread skips?

Select the correct needle size for the work being done.
Replace the needle with a new one.
Make sure the needle is inserted correctly.

What do I do when the needle skips the fabric?

Turn the penetration dial gradually towards the "more" position for greater penetration – the calibrated numbers on the dial can be noted and used for reference position for the same types of material for quick adjustment.
Check to see if the needle is blunt or damaged, replace with new one.
Check to see if the machine skip device is set on 1:1 (no skip) or 2:1 (skip) the stitch will skip the fabric every second pass if it is set on 2:1 (skip).

What do I do when too much thread is showing?

Turn the penetration dial gradually towards the "less" position **1 click at a time** for less penetration of the needle through the fabric being stitched.
Check the thread tension. Could be too tight or the thread size is incorrect.
Check the thread being used.
We recommend Polyester 65/2 for drapery blind stitch hemming – except for heavy block-out.

What do I do when the fabric is gathering?

Adjust the thread tension gradually counter clockwise to loosen the tension.

There are 2 common types of blindstitch needles: LW X 5T & LW x 6T

7200SB/DB use LW X 6T



7200SB, 7200DB, WITH POSITIONING MOTOR USER'S BULLETIN

1ST TIME USERS OF BLINDSTITCH MACHINES – PLEASE READ CAREFULLY

If you have never used a blindstitch machine before, it is very important that you read these instructions carefully.

Failure to read may limit or void the manufacturer's warranty.

Instructions:

- Activate the knee lifter. This will cause the feed plate/frame to swing downward and create a gap between the presser foot and the feed plate.
- Insert the work into the gap in such a manner that the folded or sewn edge of the material is alongside the edge guide of the presser foot.
- When the material is in the proper position, completely release the knee lifter. Run the machine slowly and watch the material pass the edge guide.
- When you're done with the seam, to remove the work from the machine, heel back on the treadle to set the looper in the forward position. (see image below).

Note:

- Activate the knee lifter, this will cause the feed plate/frame to swing downward and create a gap between the presser foot and the feed plate.
- Pull the work-piece straight back with a quick stroke. This will lock the last stitch and break the thread.
- To start another seam repeat the first three points.

Notes:

The needle must be in 100% good condition at all times, no nicks, blunt work.

When sewing flat seams make sure the work-piece is in deep under the needle to penetrate on the first stitch of sewing.

TO REMOVE THE WORK PIECE THE LOOPER MUST BE IN THIS POSITION





The machine is driven with a needle positioning motor.

On stop command the needle will always stop in the down position - (extreme right)

To remove the work piece at the end of a seam – heel back on the foot treadle and the needle will automatically position up – (extreme left)



| SIZE | LW X 6T | MATERIAL |
|-------|---------|--|
| 2 | 9 | |
| 2 1/2 | 10 | |
| 3 | 11 | Cotton, Silk, Dacron and Similar type light weight materials |
| 3 1/2 | 12 | Medium Weight materials. Woolen and others |
| 4 | 14 | Thick material for drapery and others |
| 4 1/2 | 16 | |



Reliable Corporation ("Reliable") warrants to original purchaser of its products that every product sold by Reliable (a "Reliable Product") is free from defects in material and workmanship for a period of one year from the date of purchase if properly used and maintained. Subject to the conditions and limitations set forth below, Reliable will either repair or replace any part of a Reliable Product that proves defective by reason of improper workmanship or materials. If the defective Reliable Product is no longer available and cannot be repaired effectively or replaced with an identical model, Reliable shall replace the defective Reliable Product with a current Reliable Product of equal or greater value. Repaired parts or replacement products will be provided by Reliable on an exchange basis, and will be either new or refurbished to be functionally equivalent to new. If Reliable is unable to repair or replace a Reliable Product, it will refund the current value of that Reliable Product at the time the warranty claim is made.

This limited warranty does not cover any damage to a Reliable Product that results from improper installation, accident, abuse, misuse, natural disaster, insufficient or excessive electrical supply, abnormal mechanical or environmental conditions, wear and tear resulting from normal use of the product, or any unauthorized disassembly, repair, or modification. This limited warranty does not extend to any indirect, consequential or incidental damages that may be suffered by a user or from the use of a Reliable Product, including without limitation, any liability for third party claims for damage, and is limited to the amount paid by the original purchaser Reliable Product with respect to which this limited warranty protection applies. This limited warranty does not apply with respect to products that have been altered or which are missing serial numbers or for products not purchased directly from Reliable or a dealer authorized by us to sell Reliable Products.

This limited warranty is the only warranty that applies to any Reliable Product, supersedes any and all terms that may be contained in any other document or purchase order and may not be altered or amended except expressly in writing by Reliable.

To obtain a repair or replacement under the terms of this warranty, please contact our customer service group at 1-800-268-1649 or at support@reliablecorporation.com. You will be required to submit an original receipt via fax or e-mail. The receipt must reflect that you are the original purchaser, the product was bought directly from us or from an authorized Reliable dealer and that the warranty claim is being made within the warranty period. You will be issued a return authorization number (RA#) and asked to ship the defective product together with proof of purchase and RA#, prepaid insured to the following address:

Reliable Corporation, 5-100 Wingold Avenue, Toronto, ON M6B 4K7. Freight collect shipments will be refused. The risk of loss or damage in transit will be borne by the customer. Once Reliable receives the defective product, it will initiate the repair or replacement process.

If you have any questions regarding this warranty, you may write to:

Reliable Corporation
100 Wingold Avenue, Unit 5
Toronto, Ontario
Canada M6B 4K7
www.reliablecorporation.com



1 800 268 1649
www.reliablecorporation.com